

## Daily Cleaning Manual

**TS-2** 

things to prepare before cleaning

- Kettle
- Bucket
- Toothbrush

## Useful points for cleaning

- •To enjoy your Sake, have the dispenser cleaned at least once a week. Otherwise, it will cause change in the taste of Sake and malfunction of the dispenser.
- •Upon the cleaning, please have the lid and filter washed with hot water



1.

Feed the remained Sake in the Sake tank to a Sake server bottle. Close the Sake drain cock after feeding remained Sake



2.

Dispense all the Sake left in the device with the same procedure as serving Sake. This Sake can be used for cooking as seasoning..



3.

Remove the parts (Server bottle tray, Cap, Air feeder cap and filert) and wash well with hot wate.



4

Feed water (approx.70°C) to the bottle holder to a degree not to cause overflow.

(Pay attention to an accident of scalding!!)



5

Discharge about a half of the hot water from inside through the sake drain cock into a bucket. Switch power on and push the nozzle in to



*6.* 

After draining all the hot water, gently scrub the sensor electrode at the nozzle end with a tooth brush and washing it well



7.

Wipe the machine with a cloth dipped in a neutral detergent solution or soap and water, then wipe it well with a dry cloth. Do not use paint thinner or other volatile fluids or alkaline detergents.



## **NOTICE!!**

\* First Sake dispensed from the unit might contain some water from cleaning. Please use the first feed Sake for cooking as seasning.